
TA Tips for Success in Lab

Cody Long and Yun Wu Graduate student

cslong42@students.tntech.edu ywu43@students.tntech.edu

Jan. 22 2020

Department of Mechanical Engineering Tennessee Technological University



Upload Two Files After Every Lab Challenge

- Excel Spreadsheet (.xlsx)
 - > Raw data, plots
- Challenge Report (.pdf)
 - > Clear documentation of your procedure, working notes
 - List of equipment
 - ➤ Imagine you are a year out from now, and these notes were all you had, you should be able to know what had occurred from what is written.
 - ➤ In other words, someone has never done the lab before should be able to replicate the lab by looking at your working notes.



Frequent Occurred Problems with Excel Spreadsheet Documentation


- Plots
- Page View
- **Corrupted File**



Frequent Occurred Problems with Excel Spreadsheet Documentation

Plots

- Label the plot (Y vs. X)
- > Axis
 - Scale (log scale, semi-log scale)
 - Label the axis
 - Units for each axis








Frequent Occurred Problems with Excel **Spreadsheet Documentation**

Plots

- > Use scatter plot
 - Scatter with only markers and Scatter with straight lines and markers is recommended
 - Do not use scatter with smooth lines













Excel Spreadsheet Documentation

Page View

Bad Example



Bad Example




iMS valtago calculated wing abserved waveform amplitude as desc Javeform Frequency calculated wing time period for 5 full capacits

Frequency of Input Signal f (Hz)	Magnitdue of Filtered Sianal.	Channol1Timo (Input)(sec)
10,000	4.960	0.00003
1000	4.880	0.00008
500	4.800	0.00088
300	4.720	0.00162
100	4.000	0.00112
40	2.400	0.00048
10	0.608	0.00280

ı	Cade Annatations	Timoshift calculated as difference
		Paried:
ı	OBBS MINBERCIONS	ain calculated from the ratio of output voltag
		Rozulting pharoshift calculated from
	Comments	Prozented findings of set of time shifts ass sufficiently observe and approximate data increase success of performing adequate regarding phase shifts associated with a k
		With the exception of the voltage read dadmoeneds witems over a wide range of fre

1,2000

1.0000



2.560 2.480 2.480 2.480 2.400

2.400

2.480

2.080

	Activ	vity 3	
Channol 2 Timo (Output) (roc)	Timo Shift∆t (roc)	PeriodT(rec)	Chann
0.00003	0.000001	0.0001	\top
0.00008	0.000002	0.0010	
0.00100	0.000120	0.0020	
0.00164	0.000020	0.0033	

0.000020

0.000020

0.018000

0.00114

0.00050

0.02080

boutoon input time recarded an channel 1 and autput time recarded an channel 2.
calculated fram tabling inverse of a known frequency.
one arrued an channel 2 to the input voltage mearured an channel 1 fram a given frequency
ratio of time shifts to determine a period of a given frequency converted to degrees.
conited with a given frequency input represent poor ability of laboratory personnel to
wring course band features of a function generator. Increasing scale of image of dilittle to
readings and considerably worsened ability of personnel to draw accurate conclusions
wight pass dampening capacitor arrembly for given frequencies. Suggested acuses of
ings taken for 1000 bs, gain calculations determined to be adequate for moderately
avencies. Concluded to not be a notable source of inaccuracy for this particular activity.

0.0250


0.1000




Very high variation in both observed amplit due and frequency between the oreillicape used in activity 1 and multimeter used in activity 2. Potential and suggested courtions discussed in uarking anotor along side activity 3.

Channel 2 (V_aut) (Y)	Gain G (V_aut/V_in)	Pharoshift (dog) (At/T) x 360*
2.480	0.9688	3.600
2.480	1.0000	0.720
2.400	0.9677	21.600
2.320	0.9667	2.160
2.080	0.8667	0.720
1.200	0.4839	0.288
0.304	0.1462	64.800











Good Example






■ The Difference



d-bins






Gain vs. Frequen	cy Plot (semi-log on x axis)				
1.30	Gain vs. Frequency				
		-			
0.83	5				

フ

Excel Spreadsheet Documentation

- How to setup Page View
 - View > Page Layout





Challenge Report Documentation

- List of equipments
- Labeled with number
- Clear documentation of procedure
- Following is a good example and a bad example




Good Example

Challenge 4 Working Notes

Equipment used:

1. B-102 Stain Gage with following properties



- 2. Model P-3500 Digital Strain Indicator
- 3. Beam Bending Fixture (for wire extension)



- 4. C-clamp and aluminum block
- Brass slotted weight set and hanger



> Bad Example

Challenge 4 Working Notes

Equipment used:

- 1. Stain Gage
- 2. Strain Indicator
- 3. Beam Bending Fixture (for wire extension)

- Didn't list all the equipment used
- No detailed description of which equipment is used
- No picture of which equipment is used
- If you are to replicate the lab, which working notes is easier to follow?

➤ Good Example

The setup:





> Bad Example

No drawing or picture of the setup

• If you are to replicate the lab, which working notes is easier to follow?



➤ Good Example

Activity 1: Setup

Table	e 1 -	Beam	Dimens	ions
-------	-------	------	--------	------

Beam Width, b (in)	Beam Thickness, h (in)	Moment Arm Length, L (in)
1.001	0.249	10 5/16

Note: Beam Width & Beam Thickness are measured with a Vernier Caliper, with an uncertainty of 0.0005 inch. The Moment Arm Length is measured with a ruler, with an uncertainty of 1/32 inch.

Bad Example

Activity 1: Setup


Table 1 - Beam Dimensions

Beam Width, b (in)	Beam Thickness, h (in)	Moment Arm Length, L (in)
1.001	0.249	10 5/16

- No description or indication of uncertainty
 - If you are to replicate the lab, which working notes is easier to follow?

Good Example

Activity 2: Strain Gage Connection - Axial Wiring:



Since the white wire is connected to the axial gage, I connected it with the terminal 3 of the secondary fixture. Then I looked for wires labeled as #1 and #3 in the pig tail. According to the quarter bridge arrangement, I connect #1 to the P+ terminal (red), #3 to the S- terminal, then I add a wire between S- and D120.

Then I followed steps 1-5 listed on the lid of the P-3500 unit.



> Bad Example

No drawing or picture of activity 2

• If you are to replicate the lab, which working notes is easier to follow?

Good Example

Activity 3 & 4: Loading the Beam & Strain Gage Connection - Transverse



	Table 2 - Stra	in Gage Readings			
Number of Bolts	Total Bolt Weight(s) (lbf)	Axial Gage Strain Reading, ε _a (με)	Transverse Gage Strain Reading, ε _t (με)	Bending Stress (psi) calculated	Poisson's Ratrio, v calculated
1	0.551	54	-17	549	0.31481
2	1.10	108	-34	1097	0.31481
3	1.65	161	-51	1645	0.31677
4	2.21	214	-67	2203	0.31308

Average v: 0.31487

The brass weights of 250g, 500g, 750g and 1000g is used.

I switched the white wire to the green wire, which connects to the transverse gage. The reading was shown positive but because it's on the other side of the beam, it's actually negative with respect to the axial gage.

Bad Example

Activity 2, 3 & 4: Loading the Beam & Strain Gage Connection - Transverse

	Table 2 - Stra	in Gage Readings			
Number of Bolts	Total Bolt Weight(s) (lbf)	Axial Gage Strain Reading, દુ _ઢ (μ <u>ε</u>)	Transverse Gage Strain Reading, & (ME)	Bending Stress (psi) calculated	Poisson's <u>Ratrio</u> , ∨ <i>calculated</i>
1	0.551	54	-17	549	0.31481
2	1.10	108	-34	1097	0.31481
3	1.65	161	-51	1645	0.31677
4	2.21	214	-67	2203	0.31308
			·	Average v:	0.31487

- No documentation of the procedure, no picture or drawing of the wiring
- If you are to replicate the lab, which working notes is easier to follow?



Good Example

Calculations


The Bending Moment is calculated using the equation M = F L. In which F is the total weights in lbf, L is the measured Moment Arm Length with a ruler.

M(lbf*in))
5.68	
11.3	
17.0	
22.8	

The Bending Stress on a Surface is calculated using the equation $\sigma = M \ c \ / \ I \ (c = distance from the neutral axis to the surface = h/2). In which I is calculated using I = b h' / 12. The b is the measured beam width and beam thickness with a Vernier Caliper.$


I(in^4)
0.00129
0.00129
0.00129
0.00129

Then, the Poisson's Ratio is calculated using the equation $V = - \epsilon t / \epsilon a$. The plot of the stress-strain is plotted as follows:



The Modulus of Elasticity is the slope of the linear fitting, 10Mpsi (Aluminum).

> Bad Example



The Modulus of Elasticity is the slope of the linear fitting, 10Mpsi (Aluminum).

The Modulus of Elasticity is the slope of the linear fitting, 10Mpsi (Aluminum).

- No calculation process shown, (either handwritten or typed) only shows the plot
- If you are to replicate the lab, which working notes is easier to follow?

Questions

Thanks for your attention and time!

